

## Garmin 62 Series

### Datum Check

- Press **MENU** key twice from any main page screen.
- Use Rocker to select **SETUP**
- Press **ENTER**.
- Toggle to **Units**, press **ENTER**.
- Use **ROCKER** to highlight the desired fields, press **ENTER** to select it.
- Use **ROCKER** to choose the correct field. Press **ENTER** to select.
- Set up all fields as per image (R).
- Press **QUIT** to exit.

**NOTE:**

Changing the Datum automatically converts any/all saved GR into the new datum format.



Position Format New Zealand TM
Map Datum WGS 84
Map Spheroid WGS 84

To convert a 14 digit GPS GR to a 6 digit GR for a SitRep, ignore the first 2 and last 2 numbers.

E: 1 2 3 4 5 6 7
N: 5 8 7 3 4 1 2

6 digit GR = 345734

### Clear Tracks & Waypoints

- Press **MENU** twice from any main page.
- Use **ROCKER** to select **Tracks**
- Press **ENTER**.
- Toggle to **Clear**, press **ENTER**.
- Toggle to **Yes**, press **ENTER**.
- Press **QUIT** to exit to **Main Menu**
- Press the **FIND** key
- Toggle to Waypoints, press **ENTER**.
- Press **MENU**
- Toggle to **Delete**, press **ENTER**.
- Toggle to **All Symbols**, press **ENTER**.
- Toggle to **Yes**, press **ENTER**.
- Press **QUIT** twice to exit.

### Mark Waypoint

- Press **MARK** from any page.
  - Use **ROCKER** to highlight any **field** you want to customise.
  - Press **ENTER** to select the **field**.
  - Use **ROCKER** to customise.
  - Adjust all desired fields as required.
  - Highlight **OK** & press **ENTER** to save.
- (Press **QUIT** to go back one step at any stage)

### Find/Go To Waypoint

- Press **FIND** from any page.
- Use **ROCKER** to highlight desired **Waypoint**. Press **ENTER** to select it.
- Use **ROCKER** to highlight desired waypoint, press **ENTER** to select.
- Select **Go To**.

## Garmin 62 Series

### Datum Check

- Press **MENU** key twice from any main page screen.
- Use Rocker to select **SETUP**
- Press **ENTER**.
- Toggle to **Units**, press **ENTER**.
- Use **ROCKER** to highlight the desired fields, press **ENTER** to select it.
- Use **ROCKER** to choose the correct field. Press **ENTER** to select.
- Set up all fields as per image (R).
- Press **QUIT** to exit.

**NOTE:**

Changing the Datum automatically converts any/all saved GR into the new datum format.



Position Format New Zealand TM
Map Datum WGS 84
Map Spheroid WGS 84

To convert a 14 digit GPS GR to a 6 digit GR for a SitRep, ignore the first 2 and last 2 numbers.

E: 1 2 3 4 5 6 7
N: 5 8 7 3 4 1 2

6 digit GR = 345734

### Clear Tracks & Waypoints

- Press **MENU** twice from any main page.
- Use **ROCKER** to select **Tracks**
- Press **ENTER**.
- Toggle to **Clear**, press **ENTER**.
- Toggle to **Yes**, press **ENTER**.
- Press **QUIT** to exit to **Main Menu**
- Press the **FIND** key
- Toggle to Waypoints, press **ENTER**.
- Press **MENU**
- Toggle to **Delete**, press **ENTER**.
- Toggle to **All Symbols**, press **ENTER**.
- Toggle to **Yes**, press **ENTER**.
- Press **QUIT** twice to exit.

### Mark Waypoint

- Press **MARK** from any page.
  - Use **ROCKER** to highlight any **field** you want to customise.
  - Press **ENTER** to select the **field**.
  - Use **ROCKER** to customise.
  - Adjust all desired fields as required.
  - Highlight **OK** & press **ENTER** to save.
- (Press **QUIT** to go back one step at any stage)

### Find/Go To Waypoint

- Press **FIND** from any page.
- Use **ROCKER** to highlight desired **Waypoint**. Press **ENTER** to select it.
- Use **ROCKER** to highlight desired waypoint, press **ENTER** to select.
- Select **Go To**.

## Garmin 62 Series

### Datum Check

- Press **MENU** key twice from any main page screen.
- Use Rocker to select **SETUP**
- Press **ENTER**.
- Toggle to **Units**, press **ENTER**.
- Use **ROCKER** to highlight the desired fields, press **ENTER** to select it.
- Use **ROCKER** to choose the correct field. Press **ENTER** to select.
- Set up all fields as per image (R).
- Press **QUIT** to exit.

**NOTE:**

Changing the Datum automatically converts any/all saved GR into the new datum format.



Position Format New Zealand TM
Map Datum WGS 84
Map Spheroid WGS 84

To convert a 14 digit GPS GR to a 6 digit GR for a SitRep, ignore the first 2 and last 2 numbers.

E: 1 2 3 4 5 6 7
N: 5 8 7 3 4 1 2

6 digit GR = 345734

### Clear Tracks & Waypoints

- Press **MENU** twice from any main page.
- Use **ROCKER** to select **Tracks**
- Press **ENTER**.
- Toggle to **Clear**, press **ENTER**.
- Toggle to **Yes**, press **ENTER**.
- Press **QUIT** to exit to **Main Menu**
- Press the **FIND** key
- Toggle to Waypoints, press **ENTER**.
- Press **MENU**
- Toggle to **Delete**, press **ENTER**.
- Toggle to **All Symbols**, press **ENTER**.
- Toggle to **Yes**, press **ENTER**.
- Press **QUIT** twice to exit.

### Mark Waypoint

- Press **MARK** from any page.
  - Use **ROCKER** to highlight any **field** you want to customise.
  - Press **ENTER** to select the **field**.
  - Use **ROCKER** to customise.
  - Adjust all desired fields as required.
  - Highlight **OK** & press **ENTER** to save.
- (Press **QUIT** to go back one step at any stage)

### Find/Go To Waypoint

- Press **FIND** from any page.
- Use **ROCKER** to highlight desired **Waypoint**. Press **ENTER** to select it.
- Use **ROCKER** to highlight desired waypoint, press **ENTER** to select.
- Select **Go To**.

## Garmin 62 Series

### Datum Check

- Press **MENU** key twice from any main page screen.
- Use Rocker to select **SETUP**
- Press **ENTER**.
- Toggle to **Units**, press **ENTER**.
- Use **ROCKER** to highlight the desired fields, press **ENTER** to select it.
- Use **ROCKER** to choose the correct field. Press **ENTER** to select.
- Set up all fields as per image (R).
- Press **QUIT** to exit.

**NOTE:**

Changing the Datum automatically converts any/all saved GR into the new datum format.



Position Format New Zealand TM
Map Datum WGS 84
Map Spheroid WGS 84

To convert a 14 digit GPS GR to a 6 digit GR for a SitRep, ignore the first 2 and last 2 numbers.

E: 1 2 3 4 5 6 7
N: 5 8 7 3 4 1 2

6 digit GR = 345734

### Clear Tracks & Waypoints

- Press **MENU** twice from any main page.
- Use **ROCKER** to select **Tracks**
- Press **ENTER**.
- Toggle to **Clear**, press **ENTER**.
- Toggle to **Yes**, press **ENTER**.
- Press **QUIT** to exit to **Main Menu**
- Press the **FIND** key
- Toggle to Waypoints, press **ENTER**.
- Press **MENU**
- Toggle to **Delete**, press **ENTER**.
- Toggle to **All Symbols**, press **ENTER**.
- Toggle to **Yes**, press **ENTER**.
- Press **QUIT** twice to exit.

### Mark Waypoint

- Press **MARK** from any page.
  - Use **ROCKER** to highlight any **field** you want to customise.
  - Press **ENTER** to select the **field**.
  - Use **ROCKER** to customise.
  - Adjust all desired fields as required.
  - Highlight **OK** & press **ENTER** to save.
- (Press **QUIT** to go back one step at any stage)

### Find/Go To Waypoint

- Press **FIND** from any page.
- Use **ROCKER** to highlight desired **Waypoint**. Press **ENTER** to select it.
- Use **ROCKER** to highlight desired waypoint, press **ENTER** to select.
- Select **Go To**.