

Datum Check

- Press **MENU** key twice from any main page screen.
- Use **ROCKER** to select **SETUP**.
- Press **ENTER**.
- Toggle to **POSITION FORMAT**.
- Press **ENTER**.
- Use **ROCKER** to highlight the desired field. Press **ENTER** to select the field.
- Use **ROCKER** to scroll to the correct field and press **ENTER** to select it.
- Set up all fields as per image (R).
- Press **QUIT** to exit.

NOTE:

Changing the Datum automatically converts any/all saved GR into the new datum format.

Datum Check

- Press **MENU** key twice from any main page screen.
- Use **ROCKER** to select **SETUP**.
- Press **ENTER**.
- Toggle to **POSITION FORMAT**.
- Press **ENTER**.
- Use **ROCKER** to highlight the desired field. Press **ENTER** to select the field.
- Use **ROCKER** to scroll to the correct field and press **ENTER** to select it.
- Set up all fields as per image (R).
- Press **QUIT** to exit.

NOTE:

Changing the Datum automatically converts any/all saved GR into the new datum format.

Datum Check

- Press **MENU** key twice from any main page screen.
- Use **ROCKER** to select **SETUP**.
- Press **ENTER**.
- Toggle to **POSITION FORMAT**.
- Press **ENTER**.
- Use **ROCKER** to highlight the desired field. Press **ENTER** to select the field.
- Use **ROCKER** to scroll to the correct field and press **ENTER** to select it.
- Set up all fields as per image (R).
- Press **QUIT** to exit.

NOTE:

Changing the Datum automatically converts any/all saved GR into the new datum format.

Datum Check

- Press **MENU** key twice from any main page screen.
- Use **ROCKER** to select **SETUP**.
- Press **ENTER**.
- Toggle to **POSITION FORMAT**.
- Press **ENTER**.
- Use **ROCKER** to highlight the desired field. Press **ENTER** to select the field.
- Use **ROCKER** to scroll to the correct field and press **ENTER** to select it.
- Set up all fields as per image (R).
- Press **QUIT** to exit.

NOTE:

Changing the Datum automatically converts any/all saved GR into the new datum format.

Garmin 64 Series

Position Format New Zealand TM
Map Datum WGS 84
Map Spheroid WGS 84

To convert a 14 digit GPS GR to a 6 digit GR for a SitRep, ignore the first 2 and last 2 numbers.

E: 1 2 3 4 5 6 7
N: 5 8 7 3 4 1 2
6 digit GR = 345734

Garmin 64 Series

Position Format New Zealand TM
Map Datum WGS 84
Map Spheroid WGS 84

To convert a 14 digit GPS GR to a 6 digit GR for a SitRep, ignore the first 2 and last 2 numbers.

E: 1 2 3 4 5 6 7
N: 5 8 7 3 4 1 2
6 digit GR = 345734

Garmin 64 Series

Position Format New Zealand TM
Map Datum WGS 84
Map Spheroid WGS 84

To convert a 14 digit GPS GR to a 6 digit GR for a SitRep, ignore the first 2 and last 2 numbers.

E: 1 2 3 4 5 6 7
N: 5 8 7 3 4 1 2
6 digit GR = 345734

Garmin 64 Series

Position Format New Zealand TM
Map Datum WGS 84
Map Spheroid WGS 84

To convert a 14 digit GPS GR to a 6 digit GR for a SitRep, ignore the first 2 and last 2 numbers.

E: 1 2 3 4 5 6 7
N: 5 8 7 3 4 1 2
6 digit GR = 345734

Clear Tracks & Waypoints

- Press the **MENU** key twice from any main screen page.
- Select **TRACK MANAGER**.
- Press **ENTER**.
- Select **CURRENT TRACKS**.
- Press **ENTER**.
- Use **ROCKER** to select **CLEAR CURRENT TRACK**, press **ENTER**.
- Select **YES**, press **ENTER**.
- Press **QUIT** to exit to **Main Menu**.
- Press the **FIND** key
- Toggle to **Waypoints**, press **ENTER**.
- Press **MENU**.
- Toggle to **DELETE ALL**.
- Press **ENTER**.
- Toggle to **YES**, press **ENTER**.
- Press **QUIT** twice to exit.

Clear Tracks & Waypoints

- Press the **MENU** key twice from any main screen page.
- Select **TRACK MANAGER**.
- Press **ENTER**.
- Select **CURRENT TRACKS**.
- Press **ENTER**.
- Use **ROCKER** to select **CLEAR CURRENT TRACK**, press **ENTER**.
- Select **YES**, press **ENTER**.
- Press **QUIT** to exit to **Main Menu**.
- Press the **FIND** key
- Toggle to **Waypoints**, press **ENTER**.
- Press **MENU**.
- Toggle to **DELETE ALL**.
- Press **ENTER**.
- Toggle to **YES**, press **ENTER**.
- Press **QUIT** twice to exit.

Clear Tracks & Waypoints

- Press the **MENU** key twice from any main screen page.
- Select **TRACK MANAGER**.
- Press **ENTER**.
- Select **CURRENT TRACKS**.
- Press **ENTER**.
- Use **ROCKER** to select **CLEAR CURRENT TRACK**, press **ENTER**.
- Select **YES**, press **ENTER**.
- Press **QUIT** to exit to **Main Menu**.
- Press the **FIND** key
- Toggle to **Waypoints**, press **ENTER**.
- Press **MENU**.
- Toggle to **DELETE ALL**.
- Press **ENTER**.
- Toggle to **YES**, press **ENTER**.
- Press **QUIT** twice to exit.

Clear Tracks & Waypoints

- Press the **MENU** key twice from any main screen page.
- Select **TRACK MANAGER**.
- Press **ENTER**.
- Select **CURRENT TRACKS**.
- Press **ENTER**.
- Use **ROCKER** to select **CLEAR CURRENT TRACK**, press **ENTER**.
- Select **YES**, press **ENTER**.
- Press **QUIT** to exit to **Main Menu**.
- Press the **FIND** key
- Toggle to **Waypoints**, press **ENTER**.
- Press **MENU**.
- Toggle to **DELETE ALL**.
- Press **ENTER**.
- Toggle to **YES**, press **ENTER**.
- Press **QUIT** twice to exit.

Waypoint Create

- Press **MARK** from any page.
- Use **ROCKER** to highlight any field you want to customise.
- Press **ENTER** to select field.
- Use **ROCKER** to customise.
- Press **QUIT** to go back one step.
- Adjust all fields to desired settings.
- Highlight **DONE** & press **ENTER** to finish.
(Use **QUIT** to go back one step at any stage)

Waypoints - Find/Go To

- Press **FIND** from any page.
- Use **ROCKER** to highlight **Waypoint**.
- Press **ENTER** to select.
- Use **ROCKER** to highlight desired waypoint. Press **ENTER** to select.
- Select **GO**.

Waypoint Create

- Press **MARK** from any page.
- Use **ROCKER** to highlight any field you want to customise.
- Press **ENTER** to select field.
- Use **ROCKER** to customise.
- Press **QUIT** to go back one step.
- Adjust all fields to desired settings.
- Highlight **DONE** & press **ENTER** to finish.
(Use **QUIT** to go back one step at any stage)

Waypoints - Find/Go To

- Press **FIND** from any page.
- Use **ROCKER** to highlight **Waypoint**.
- Press **ENTER** to select.
- Use **ROCKER** to highlight desired waypoint. Press **ENTER** to select.
- Select **GO**.

Waypoint Create

- Press **MARK** from any page.
- Use **ROCKER** to highlight any field you want to customise.
- Press **ENTER** to select field.
- Use **ROCKER** to customise.
- Press **QUIT** to go back one step.
- Adjust all fields to desired settings.
- Highlight **DONE** & press **ENTER** to finish.
(Use **QUIT** to go back one step at any stage)

Waypoints - Find/Go To

- Press **FIND** from any page.
- Use **ROCKER** to highlight **Waypoint**.
- Press **ENTER** to select.
- Use **ROCKER** to highlight desired waypoint. Press **ENTER** to select.
- Select **GO**.

Waypoint Create

- Press **MARK** from any page.
- Use **ROCKER** to highlight any field you want to customise.
- Press **ENTER** to select field.
- Use **ROCKER** to customise.
- Press **QUIT** to go back one step.
- Adjust all fields to desired settings.
- Highlight **DONE** & press **ENTER** to finish.
(Use **QUIT** to go back one step at any stage)

Waypoints - Find/Go To

- Press **FIND** from any page.
- Use **ROCKER** to highlight **Waypoint**.
- Press **ENTER** to select.
- Use **ROCKER** to highlight desired waypoint. Press **ENTER** to select.
- Select **GO**.