

Check/Change Datum

- Press **MENU** key twice from any main page screen.
- Use **ROCKER** to select **SETUP**
- Press **ENTER**
- Toggle to **UNITS**, Press **ENTER**.
- Use the **ROCKER** to highlight the desired field. Press **ENTER** to select.
- Use **ROCKER** to choose the correct field and **ENTER** to select.
- Set up all fields as per image.
- Press **QUIT** to exit.

Garmin 60 Series Pocket Reference

Position Format	New Zealand TM	▼
Map Datum	WGS 84	▼
Distance/Speed	Metric	▼
Elevation (Vert. Speed)	Meters (m/min)	▼
Depth	Meters	▼
Temperature	Celsius	▼
Pressure	Millibars	▼

Clear Tracks & Waypoints

- Press the **MENU** key twice from any main screen page.
- Use **ROCKER** to select **Tracks**.
- Press **ENTER**.
- Toggle to **Clear**, Press **ENTER**.
- Toggle to **Yes**, Press **ENTER**.
- Press **QUIT** to exit to Main Menu.
- Press the **FIND** key.
- Toggle to **Waypoints**, press **ENTER**.
- Press **MENU**.
- Toggle to **Delete**, press **ENTER**.
- Toggle to **All Symbols**, press **ENTER**.
- Toggle to **Yes**, Press **ENTER**.
- Press **QUIT** twice to exit.

Waypoints - Create

- Press **MARK** from any page.
- Use **ROCKER** to highlight any field you want to customise.
- Press **ENTER** to select field.
- Use **ROCKER** to customise.
- Press **QUIT** to go back one step.
- Adjust all desired fields.
- Highlight **OK** & press **ENTER** to finish.

Waypoints - Find/Go To

- Press **FIND** from any page.
- Use **ROCKER** to highlight **Waypoint**.
- Press **ENTER** to select
- Use **ROCKER** to highlight waypoint, press **ENTER**.
- Select **Go To**.